



FACSIMILE EQUIPMENT

PARTS REFERENCE LIST

MODEL: FAX1815C / FAX1820C

MFC3220C / MFC3320CN

**(For Germany / United Kingdom / France /
Belgium / Netherlands / Switzerland /
Ireland / Denmark / Austria / Spain / Italy /
Portugal / Hong Kong / Singapore /
Gulf / Euro Generic / Australia /
New Zealand / Finland / Norway / Sweden)**

© Copyright Brother 2003

All rights reserved

No part of this publication may be reproduced in any form or by any means without permission in writing from the publisher.

Specifications are subject to change without prior notice.

NOTES FOR USING THIS PARTS REFERENCE LIST

1. In the case of ordering parts, it needs mentioning the following items:

- (1) Code
- (2) Q' ty
- (3) Description

Note: No orders without Parts Code or Tool No. can be accepted.

[Example]

REF.NO.	CODE	Q' TY	DESCRIPTION	REMARKS

2. Design-changed parts:

When the parts are changed, any one of the following symbols is mentioned in the REMARKS column.

CNG(cng) : The part is changed to a new part.

ADD(add) : The part is newly added.

DEL(del) : The part is deleted.


Symbol in capital letters indicates that the change is the latest one in the page.

3. Parts change will be informed by the technical information.

COUNTRIES

GERMAN ----- GER
 UNITED KINGDOM ----- UK
 FRANCE ---- FRA
 BELGIUM ---- BEL
 NETHERLANDS ---- NLD
 SWITZERLAND ---- CHE
 IRELAND ---- IRE
 DENMARK ---- DEN
 AUSTRIA ---- AUS
 SPAIN ---- SPA
 ITALY ---- ITA
 PORTUGAL ---- POR
 HONG KONG ---- HK
 SIN ---- SINGAPORE
 GUL ---- GULF
 EURO GENERIC ---- GNR
 AUSTRALIA ---- ARL
 NEW ZEALAND ---- NZ
 FINLAND ---- FIN
 NORWAY ---- NOR
 SWEDEN ---- SWE


1. SCANNER



List1(SCANNER)

REF No.	CODE	QTY	DESCRIPTION	RECOMMEND	REMARK
1	LE3953002	1	UPPER COVER ASSY FOR FAX1815C		
1	LE9896001	1	UPPER COVER ASSY FOR FAX1820C		
1	LE3953001	1	UPPER COVER ASSY FOR MFC3220C		
1	LE9926001	1	UPPER COVER ASSY FOR MFC3320CN		
1-1	LE3954002	1	UPPER COVER FOR FAX1815C		
1-1	LE9897001	1	UPPER COVER, GRAY(1495) FOR FAX1820C		
1-1	LE3954001	1	UPPER COVER, GRAY(1581)FOR MFC3220C		
1-1	LE9927001	1	UPPER COVER, GRAY(1581)FOR MFC3320CN		
1-2	UU0021001	1	PRESSER ROLLER		
1-3	LE2472001	2	PRESSER ROLLER SPRING		
1-4	LE2471001	2	PRESSURE ROLLER SHAFT		
1-5	LE3957001	1	SCANNER DRIVE UNIT		
1-5-1	LE9865001	1	SCANNING MOTOR ASSY		
1-5-2	0A4300605	1	SCREW, PAN (S/P WASHER) M3X6		
1-6	UU7030001	1	SEPARATION ROLLER GEAR		
1-7	LF5446001	1	SEPARATION ROLLER		CHG
1-8	LE6325001	1	BUSHING 12		
1-9	LE6326001	1	BUSHING 6		
1-10	LE3965001	1	DOCUMENT EJECTION ROLLER ASSY		
1-11	LE3967001	1	DOCUMENT FEED ROLLER ASSY2		
1-12	UF8105001	2	BUSHING		
1-13	LF4230001	2	PAWLED PLASTIC BUSHING		chg
1-14	UU7039001	2	LF ROLLER GEAR 27		
1-15	UU2028001	2	CIS SPRING		
1-16	LF4353001	1	CIS SIDE SPRING		
1-17	LG4671001	1	CIS UNIT	√	
1-18	LG4672001	1	CIS FLAT CABLE		
1-19	087311016	7	TAPTITE, CUP B M3X10		
1-20	UL6244002	2	PINCH ROLLER		
2	087320616	1	TAPTITE, CUP S M3X6		
3	085411216	2	TAPTITE, BIND B M4X12		
4	LE9898001	1	HANDSET HOLDER ASSY, GRAY(1495) FOR FAX1820C		
5	LF4140001	1	SOUNDPROOF FOAM		


2.ENGINE



List2(ENGINE)


REF No	CODE	QTY	DESCRIPTION	RECOMMEND	SYMBOL	REMARK
1	LE3996001	1	CARRIAGE UNIT ASSY	√		
1-1	LE6930001	2	HEAD CLAMP SPRING			
1-2	LE6935001	1	CR PCB FILM ASSY			
1-2-1	LE6940001	1	SLIDE FILM PCB			
2	0A5300605	2	SCREW, PAN (S/P WASHER) M3X6			
3	LE6945001	1	TIMING BELT M			
4	LE6946001	1	CARRIAGE MOTOR			
5	087320616	1	TAPTITE, CUP S M3X6			
6	LE6956001	1	ENCODER STRIP			
7	LE9725001	1	ENCODER STRIP SPRING			
8	087310815	2	TAPTITE, CUP B M3X8			
9	000300505	3	SCREW, BIND M3X5			
10	LG4745001	1	INK EMPTY SENSOR SUPPORT ASSY		B53K704	
11	LF5569001	1	STAR WHEEL SUPPORT ASSY (SP)			chg
12	LE9229001	2	TAPTITE, PAN B 3X10			
13	LE6962001	1	PRESSURE ROLLER HOLDER ASSY			
14	LE6967001	2	ACTUATOR			
15	LE6968001	2	ACTUATOR SPRING			
16	LF4083001	1	PLATEN			
17	LE6974002	1	PF ROLLER ASSY, BLUE MARK(SP)			CHG
17	LE6974003	1	PF ROLLER ASSY, RED MARK(SP)			CHG
18	LF5567001	1	PAPER EJECTION ROLLER ASSY (SP)			chg
19	LE6985001	1	PF MOTOR GEAR ASSY			
20	LE6988001	1	PURGE UNIT	√		
20-1	LG4678001	1	PURGE SWITCH HARNESS			
21	LG4994001	1	DRIVER PCB ASSY	√	B53K678	
22	LE6966001	4	PRESSURE ROLLER SPRING			add

3.HEAD UNIT



List3(HEAD UNIT)


REF No.	CODE	QTY	DESCRIPTION	RECOMMEND	REMARK
1	LK0935001	1	PRINT HEAD UNIT (SP)	√	
1-1	LK0516001	1	HEAD NOZZLE SEAL (SP)	√	
1-2	LK1870001	1	HEAD FILTER SEAL (SP)	√	CHG



List4(ASF)

REF No.	CODE	QTY	DESCRIPTION	RECOMMEND	REMARK
1	LE9656001	1	ASF BASE L2 ASSY, GRAY(1581)	√	
1-1	LE9658001	1	BANK ASSY		
1-2	085311015	2	SCREW, BIND B TITE 3X10		
1-3	LE9672001	1	ASF ROLLER ASSY		
2	087320616	4	TAPTITE, CUP S M3X6		

5.COVER




8XA701/705/711/717/730
/731/741/747

FAX1815C/1820C/1920CN/ MFC3220C/3320CN

List5(COVER)

REF No	CODE	QTY	DESCRIPTION	RECOMMEND	REMARK
1	LE9679001	1	LOWER COVER ASSY, GRAY(1677)		
1-1	UD4019001	2	RUBBER FOOT		
2	LE9681001	1	INK ABSORBER ASSY		
3	LE9164001	1	TUBE FIT D		
4	LE9684001	1	CONNECT TUBE		
5	LG3845001	1	SPEAKER		
6	LE9704002	1	TOP COVER ASSY, GRAY(1495) FOR FAX1815C/1820C		
6	LE9704001	1	TOP COVER ASSY, GRAY(1581) FOR MFC3220C		
6	LE9704004	1	TOP COVER ASSY, GRAY(1581) FOR MFC3320CN		
7	LE9689002	1	REAR COVER L, GRAY(1495) FOR FAX1815C/1820C		
7	LE9689001	1	REAR COVER L, GRAY(1581) FOR MFC3220C		
7	LE9909001	1	REAR COVER L, GRAY(1581) FOR MFC3320CN		
8	LE9690002	1	REAR COVER R, GRAY(1495) FOR FAX1815C/1820C		
8	LE9690001	1	REAR COVER R, GRAY(1581) FOR MFC3220C/3320CN		
9	087320616	24	TAPTITE, CUP S M3X6		
10	002300616	1	SCREW, PAN M3X6		
11	087311016	2	TAPTITE, CUP B M3X10		
12	UF6559001	1	SCREW, PAN (WASHER) M4X8DB		
13	085411216	9	TAPTITE, BIND B M4X12		
14	LE9720001	1	INK REPLACE INSTRUCTION LABEL		
15	LF4086001	1	CONSUMPTION LABEL LC800		
16	UU0456001	1	PROTECTION PAPER		
17	LE9887001	1	MEDIA MODULE FOR MFC3320CN		
17-1	LE9889001	1	MEDIA COVER FOR MFC3320CN		
18	LE9918001	1	MEDIA FFC 21P BENDING ASSY FOR MFC3320CN		
19	LE9919001	1	MEDIA FFC 22P BENDING ASSY FOR MFC3320CN		
20	LF4429001	1	CORE SUPPORT		
21	LF4144004	4	SOUNDPROOF FOAM		DEL
22	087411216	2	TAPTITE, CUP B M4X12		
23	----		NOT USED		
24	LF4475001	1	USB STICKER		

6.PANEL



List6(PANEL)


REF No.	CODE	QTY	DESCRIPTION	RECOMMEND	SYMBOL	REMARK
1	LF4090001	1	CONTROL PANEL ASSY, FAX1815C FOR GER/AUS	√		
1	LF4110001	1	CONTROL PANEL ASSY, FAX1820C FOR GER/AUS	√		
1	LE9992001	1	CONTROL PANEL ASSY, MFC3220C FOR GER/AUS	√		
1	LF4174001	1	CONTROL PANEL ASSY, MFC3320CN FOR GER/AUS	√		
1	LF4118001	1	CONTROL PANEL ASSY, FAX1820C FOR UK/BEL/CHE/IRE/GNR	√		
1	LE9994001	1	CONTROL PANEL ASSY, MFC3220C FOR UK/BEL/CHE/IRE/GNR	√		
1	LF4185001	1	CONTROL PANEL ASSY, FAX3320CN FOR UK/BEL/CHE/IRE/GNR	√		
1	LF4100001	1	CONTROL PANEL ASSY, FAX1815C FOR FRA	√		
1	LF4126001	1	CONTROL PANEL ASSY, FAX1820C FOR FRA	√		
1	LE9996001	1	CONTROL PANEL ASSY, MFC3220C FOR FRA	√		
1	LF4193001	1	CONTROL PANEL ASSY, MFC3320CN FOR FRA	√		
1	LF4486001	1	CONTROL PANEL ASSY, FAX1820C FOR NLD	√		
1	LF4343001	1	CONTROL PANEL ASSY, MFC3220C FOR NLD	√		
1	LF4571001	1	CONTROL PANEL ASSY, MFC3320CN FOR NLD	√		
1	LF4435001	1	CONTROL PANEL ASSY, FAX1815C FOR CHE	√		
1	LF4492001	1	CONTROL PANEL ASSY, FAX1820C FOR DEN/NOR/FIN/SWE	√		
1	LF4308001	1	CONTROL PANEL ASSY, MFC3220C FOR DEN/NOR/FIN/SWE	√		
1	LF4581001	1	CONTROL PANEL ASSY, MFC3320CN FOR DEN/NOR/FIN/SWE	√		
1	LF4441001	1	CONTROL PANEL ASSY, FAX1815C FOR SPA	√		
1	LF4497001	1	CONTROL PANEL ASSY, FAX1820C FOR SPA	√		
1	LF4319001	1	CONTROL PANEL ASSY, MFC3220C FOR SPA	√		
1	LF4417001	1	CONTROL PANEL ASSY, MFC3320CN FOR SPA	√		
1	LF4500001	1	CONTROL PANEL ASSY, FAX1820C FOR ITA	√		
1	LF4324001	1	CONTROL PANEL ASSY, MFC3220C FOR ITA	√		
1	LF4423001	1	CONTROL PANEL ASSY, MFC3320CN FOR ITA	√		
1	LF4445001	1	CONTROL PANEL ASSY, FAX1815C FOR POR	√		
1	LF4504001	1	CONTROL PANEL ASSY, FAX1820C FOR POR	√		
1	LF4329001	1	CONTROL PANEL ASSY, MFC3220C FOR POR	√		
1	LF4588001	1	CONTROL PANEL ASSY, MFC3320CN FOR POR	√		
1	LF4682001	1	CONTROL PANEL ASSY, FAX1820C FOR SIN/GUL/ARL/NZ	√		
1	LF4516001	1	CONTROL PANEL ASSY, MFC3220C FOR HK/SIN/GUL/ARL/NZ	√		
1-1	LF4089001	1	PRINTED PANEL ASSY, GRAY(1495), FAX1815C FOR GER/AUS			
1-1	LF4111001	1	PRINTED PANEL ASSY, GRAY(1495), FAX1820C FOR GER/AUS			
1-1	LE9993001	1	PRINTED PANEL ASSY, GRAY(1581), MFC3220C FOR GER/AUS			
1-1	LF4175001	1	PRINTED PANEL ASSY, GRAY(1581), MFC3320CN FOR GER/AUS			
1-1	LF4119001	1	PRINTED PANEL ASSY, GRAY(1495), FAX1820C FOR UK/BEL/CHE/IRE/GNR			
1-1	LE9995001	1	PRINTED PANEL ASSY, GRAY(1581), MFC3220C FOR UK/BEL/CHE/IRE/GNR			
1-1	LF4186001	1	PRINTED PANEL ASSY, GRAY(1581), MFC3320CN FOR			
1-1	LF4101001	1	PRINTED PANEL ASSY, GRAY(1495), FAX1815C FOR FRA			
1-1	LF4127001	1	PRINTED PANEL ASSY, GRAY(1495), FAX1820C FOR FRA			
1-1	LE9997001	1	PRINTED PANEL ASSY, GRAY(1581), MFC3220C FOR FRA			
1-1	LF4194001	1	PRINTED PANEL ASSY, GRAY(1581), MFC3320CN FOR FRA			
1-1	LF4487001	1	PRINTED PANEL ASSY, GRAY(1495), FAX1820C FOR NLD			
1-1	LF4344001	1	PRINTED PANEL ASSY, GRAY(1581), MFC3220C FOR NLD			
1-1	LF4572001	1	PRINTED PANEL ASSY, GRAY(1581), MFC3320CN FOR NLD			
1-1	LF4436001	1	PRINTED PANEL ASSY, GRAY(1495), FAX1815C FOR CHE			
1-1	LF4493001	1	PRINTED PANEL ASSY, GRAY(1495), FAX1820C FOR DEN/NOR/FIN/SWE			
1-1	LF4582001	1	PRINTED PANEL ASSY, GRAY(1495), MFC3320CN FOR DEN/NOR/FIN/SWE			
1-1	LF4309001	1	PRINTED PANEL ASSY, GRAY(1581), MFC3220C FOR DEN/NOR/FIN/SWE			
1-1	LF4442001	1	PRINTED PANEL ASSY, GRAY(1495), FAX1815C FOR SPA			
1-1	LF4498001	1	PRINTED PANEL ASSY, GRAY(1495), FAX1820C FOR SPA			
1-1	LF4320001	1	PRINTED PANEL ASSY, GRAY(1495), MFC3220C FOR SPA			
1-1	LF4418001	1	PRINTED PANEL ASSY, GRAY(1581), MFC3320CN FOR SPA			
1-1	LF4501001	1	PRINTED PANEL ASSY, GRAY(1495), FAX1820C FOR ITA			
1-1	LF4325001	1	PRINTED PANEL ASSY, GRAY(1495), MFC3220C FOR ITA			
1-1	LF4424001	1	PRINTED PANEL ASSY, GRAY(1581), MFC3320CN FOR ITA			
1-1	LF4446001	1	PRINTED PANEL ASSY, GRAY(1495), FAX1815C FOR POR			
1-1	LF4505001	1	PRINTED PANEL ASSY, GRAY(1495), FAX1820C FOR POR			
1-1	LF4330001	1	PRINTED PANEL ASSY, GRAY(1495), MFC3220C FOR POR			
1-1	LF4589001	1	PRINTED PANEL ASSY, GRAY(1495), MFC3320CN FOR POR			
1-1	LF4683001	1	PRINTED PANEL ASSY, GRAY(1495), FAX1820C FOR SIN/GUL/ARL/NZ			
1-1	LF4517001	1	PRINTED PANEL ASSY, GRAY(1495), MFC3220C FOR HK/SIN/GUL/ARL/NZ			

List6(PANEL)

REF No	CODE	QTY	DESCRIPTION	RECOMMEND	SYMBOL	REMARK
1-2	LF4091001	1	RUBBER KEYPAD, FAX1815C/1820C FOR GER/AUS			
1-2	LE9902001	1	RUBBER KEYPAD, FAX1815C/1820C EXCEPT FOR GER/AUS			
1-2	LF4153001	1	RUBBER KEYPAD, MFC3220C FOR GER/AUS			
1-2	LE9869001	1	RUBBER KEYPAD, MFC3220C FOR EXCEPT FOR GER/AUS			
1-2	LF4176001	1	RUBBER KEYPAD, MFC3320CN FOR GER/AUS			
1-2	LE9916001	1	RUBBER KEYPAD, MFC3320CN EXCEPT FOR GER/AUS			
1-3	LG4703003	1	CONTROL PANEL PCB ASSY FOR FAX1815C/1820C		B53K680	
1-3	LG4703001	1	CONTROL PANEL PCB ASSY FOR MFC3220C		B53K680	
1-3	LG4703002	1	CONTROL PANEL PCB ASSY FOR MFC3320CN		B53K680	
1-4	LE9698001	1	PANEL REAR COVER			
1-5	LE3330001	1	ADF SPRING PLATE B			
1-6	LE3299001	1	SEPARATION RUBBER			
1-7	LE3300001	1	ADF SPRING PLATE A			
1-8	LE3323001	2	ADF GUIDE CAP			
1-9	UF6116002	1	TAPTITE, PAN B M3X6			
1-10	LE6176001	1	DOCUMENT FRONT SENSOR ACTUATOR			
1-11	LE6177001	1	DOCUMENT REAR SENSOR ACTUATOR			
1-12	LE9991001	2	SPRING			
1-13	LE9701001	1	DOCUMENT PRESSURE BAR ASSY			
1-14	087310615	3	TAPTITE, CUP B M3X6			
1-15	LF4092001	1	LCD SHEET FOR FAX1815			
1-15	LF4112001	1	LCD SHEET FOR FAX1820			
1-15	LE9707001	1	LCD SHEET FOR MFC3220C			
1-15	LE9917001	1	LCD SHEET FOR MFC3320CN			

CHG


7. PCB



List7(PCB)

REF No.	CODE	QTY	DESCRIPTION	RECOMMEND	SYMBOL	REMARK
1	LG4688003	1	MAIN PCB FOR FAX1815C/MFC3220C	√	B53K674	
1	LG4793026	1	MAIN PCB, FAX1820C FOR ARL/NZ	√	B53K674	ADD
1	LG4793023	1	MAIN PCB, FAX1820C EXCEPT FOR ARL/NZ	√	B53K674	
1	LG4789003	1	MAIN PCB FOR MFC3320CN	√	B53K705	
2	LG4425011	1	NCU PCB ASSY, FAX1815C, MFC3220C FOR GER/UK/FRA/BEL/NLD/ CHE/IRE/DEN/AUS/SPA/ITA/POR/GNR/NOR/FIN/SWE	√	B53K666	
2	LG4833061	1	NCU PCB ASSY, FAX1820C FOR GER/UK/FRA/BEL/NLD/ CHE/IRE/DEN/AUS/SPA/ITA/POR/GNR/NOR/FIN/SWE	√	B53K666	
2	LG4835063	1	NCU PCB ASSY, FAX1820C FOR SIN/GUL	√	B53K666	
2	LG4520013	1	NCU PCB ASSY, MFC3220C FOR HK/SIN/GUL	√	B53K666	
2	LG4835065	1	NCU PCB ASSY, FAX1820C FOR ARL/NZ	√	B53K666	
2	LG4520015	1	NCU PCB ASSY, MFC3220C FOR ARL/NZ	√	B53K666	
3	LG4817001	1	POWER SUPPLY PCB ASSY FOR GER/UK/FRA/BEL/NLD/ CHE/IRE/DEN/AUS/SPA/ITA/POR/GNR/ARL/NZ/NOR/FIN/SWE (NOT INCLUDING AC CORD)	√		
3	LG4819001	1	POWER SUPPLY PCB ASSY FOR HK/SIN/GUL (NOT INCLUDING AC CORD)	√		
4	LG4808001	1	SDAA PCB ASSY FOR MFC3320CN	√	B53K710	
5	LG4855018	1	MJ PCB ASSY FOR MFC3320CN	√	B53K711	chg
6	U83026000	1	WIRE TIE 100	√		


8.ACCESSORIES



List8(Accessories)

REF No	CODE	QTY	DESCRIPTION	RECOMMEND	REMARK
1	UG3625001	1	TELEPHONE LINE CORD FOR GER		
1	UG3626001	1	TELEPHONE LINE CORD FOR UK		
1	UG3627001	1	TELEPHONE LINE CORD FOR FRA		
1	UG1575001	1	TELEPHONE LINE CORD FOR BEL		
1	LG3077001	1	TELEPHONE LINE CORD FOR NLD/IRE/SPA/POR/SIN/GUL/ARL/NZ/GNR		
1	UG3469000	1	TELEPHONE LINE CORD FOR CHE		
1	LG5827001	1	TELEPHONE LINE CORD FOR DEN/SWE/FIN/NOR		CHG
1	UG4205001	1	TELEPHONE LINE CORD FOR AUS		
1	UG3634001	1	TELEPHONE LINE CORD FOR ITA		
1	UG3635001	4	TELEPHONE LINE CORD FOR SWE		DEL
1	UG3632004	4	TELEPHONE LINE CORD FOR FIN		DEL
1	UG3629004	4	TELEPHONE LINE CORD FOR NOR		DEL
1	UG3290001	1	TELEPHONE LINE CORD FOR HK/ARL/NZ		
2	LE9840002	1	OUTPUT PAPER SUPPORT FOR FAX1815C/1820C		
2	LE9840001	1	OUTPUT PAPER SUPPORT FOR MFC3220C/3320CN		
3	LF4352002	1	ADF DOCUMENT SUPPORT, PURPLE(6255) FOR FAX1815C/1820C		
3	LF4352003	1	ADF DOCUMENT SUPPORT, GRAY(1676) FOR MFC3220C/3320CN		
4	LE3305001	1	ADF DOCUMENT OUTPUT SUPPORT		
5	LE9709002	1	PAPER TRAY ASSY, PURPLE(6255) FOR FAX1815C/1820C		
5	LE9709001	1	PAPER TRAY ASSY, GRAY(1676) FOR MFC3220C/3320CN		
6	LF4154001	1	CD-ROM ASSY, MFC3220C FOR GER/UK/FRA/CHE/IRE/AUS/HK/SIN/GUL/ARL/NZ		
6	LF4177001	1	CD-ROM ASSY, MFC3320CN FOR GER/UK/FRA/CHE/IRE/AUS		
6	LF4293001	1	CD-ROM ASSY, MFC3220C FOR BEL/NLD/GNR/NOR/FIN/SWE		
6	LF4455001	1	CD-ROM ASSY, MFC3320CN FOR BEL/NLD/GNR/NOR/FIN/SWE		
6	LF4294001	1	CD-ROM ASSY, MFC3220C FOR DEN/NOR/FIN/SWE		
6	LF4456001	1	CD-ROM ASSY, MFC3320CN FOR DEN/NOR/FIN/SWE		
6	LF4292001	1	CD-ROM ASSY, MFC3220C FOR SPA/ITA/POR		
6	LF4419001	1	CD-ROM ASSY, MFC3320CN FOR SPA/ITA/POR		
6	LF4155001	1	CD-ROM ASSY, MAC, MFC3220C FOR GER/UK/FRA/CHE/IRE/AUS/HK/SIN/GUL/GNR/ARL/NZ		
6	LF4476001	1	CD-ROM ASSY, MAC, MFC3320CN FOR GER/UK/FRA/CHE/IRE/AUS/SPA/ITA/GNR		
6	LF4450001	1	CD-ROM ASSY, MAC, MFC3220C FOR BEL/NLD/DEN/SPA/ITA/POR/NOR/FIN/SWE		
6	LF4451001	1	CD-ROM ASSY, MAC, MFC3320CN FOR BEL/NLD/DEN/POR/NOR/FIN/SWE		
7	ZA0310001	1	HEAD CLEANER STICK ASSY	√	
8	LK1103001	1	IL CARTRIDGE LC31	√	
9	LK0504001	1	GLYCEROL CLEAN FLUID BH	√	
10	LF4005001	1	FORM EMPTY CARTRIDGE BHL2 UNIT	√	
11	UF9258001	1	COLOR TEST CHART CTC-001		
12	UF8263001	1	TEST CHART-027		
13	LF1518011	1	HANDSET ASSY, GRAY(1495) FOR FAX1820C		
14	LF4407001	1	HANDSET CURLED CORD ASSY, GRAY(1495) FOR FAX1820C		
15	LG3622001	1	TELEPHONE PLUG FOR NLD		
15	LG3509001	1	TELEPHONE PLUG FOR ARL/NZ		
15	LG5828001	1	TELEPHONE PLUG FOR DEN		ADD
15	LG5829001	1	TELEPHONE PLUG FOR FIN		ADD
15	LG5830001	1	TELEPHONE PLUG FOR SWE		ADD
16	LG5717001	1	AC CORD BAG ASSY, VDE FOR GER/FRA/BEL/NLD/AUS/SPA/ITA/POR/GUL		chg
16	LG5692001	1	AC CORD BAG ASSY FOR UK/IRE/HK/SIN		chg
16	LG2087001	1	AC CORD BAG ASSY, SEV FOR CHE		
16	LG2181001	1	AC CORD BAG ASSY, DEMKO FOR DEN		
16	LJ9667001	1	AC CORD BAG ASSY, SAA FOR ARL/NZ		chg


9. PRINTED MATTER



List9(PRINTED MATTER)

REF No.	CODE	Q'TY	DESCRIPTION	RECOMMEND	REMARK
1	LF4113003	1	USER'S GUIDE ASSY, FAX1815C/1820C FOR GER	√	
1	LF4529003	1	USER'S GUIDE ASSY, MFC3220C FOR GER	√	
1	LF4178003	1	USER'S GUIDE ASSY, MFC3320CN FOR GER	√	
1	LF4120004	1	USER'S GUIDE ASSY, FAX1820C/MFC3220C FOR UK	√	
1	LF4187004	1	USER'S GUIDE ASSY, MFC3320CN FOR UK	√	
1	LF4128005	1	USER'S GUIDE ASSY, FAX1815C/1820C/MFC3220C FOR FRA	√	
1	LF4195005	1	USER'S GUIDE ASSY, MFC3320CN FOR FRA	√	
1	LF4295008	1	USER'S GUIDE ASSY, FAX1820C/MFC3220C FOR BEL	√	
1	LF4566008	1	USER'S GUIDE ASSY, MFC3320CN FOR BEL	√	
1	LF4300009	1	USER'S GUIDE ASSY, FAX1820C/MFC3220C FOR NLD	√	
1	LF4573009	1	USER'S GUIDE ASSY, MFC3320CN FOR NLD	√	
1	LF4303010	1	USER'S GUIDE ASSY, FAX1815C/1820C/MFC3220C FOR CHE	√	
1	LF4576010	1	USER'S GUIDE ASSY, MFC3320CN FOR CHE	√	
1	LF4306011	1	USER'S GUIDE ASSY, FAX1820C/MFC3220C FOR IRE	√	
1	LF4579011	1	USER'S GUIDE ASSY, MFC3320CN FOR IRE	√	
1	LF4314013	1	USER'S GUIDE ASSY, FAX1820C/MFC3220C FOR DEN	√	
1	LF4583013	1	USER'S GUIDE ASSY, MFC3320CN FOR DEN	√	
1	LF4317014	1	USER'S GUIDE ASSY, FAX1815C/1820C FOR AUS	√	
1	LF4530014	1	USER'S GUIDE ASSY, MFC3220C FOR AUS	√	
1	LF4586014	1	USER'S GUIDE ASSY, MFC3320CN FOR AUS	√	
1	LF4321015	1	USER'S GUIDE ASSY, FAX1815C/1820C/MFC3220C FOR SPA	√	
1	LF4420015	1	USER'S GUIDE ASSY, MFC3320CN FOR SPA	√	
1	LF4326016	1	USER'S GUIDE ASSY, FAX1820C/MFC3220C FOR ITA	√	
1	LF4425016	1	USER'S GUIDE ASSY, MFC3320CN FOR ITA	√	
1	LF4331018	1	USER'S GUIDE ASSY, FAX1815C/1820C/MFC3220C FOR POR	√	
1	LF4590018	1	USER'S GUIDE ASSY, MFC3320CN FOR POR	√	
1	LF4482028	1	USER'S GUIDE ASSY, MFC3220C FOR HK	√	
1	LF4518056	1	USER'S GUIDE ASSY, FAX1820C/MFC3220C FOR SIN/GUL/ARL/NZ	√	
1	LF4337057	1	USER'S GUIDE ASSY, MFC3220C FOR NOR/FIN/SWE	√	CHG
1	LF4596057	1	USER'S GUIDE ASSY, MFC3320CN FOR NOR/FIN/SWE	√	
1	LF5046057	1	USER'S GUIDE ASSY, FAX1820C FOR NOR/SWE	√	ADD
1	LF5047012	1	USER'S GUIDE ASSY, FAX1820C FOR FIN	√	ADD
1	LF4334054	1	USER'S GUIDE ASSY, FAX1820C/MFC3220C FOR GNR	√	
1	LF4593054	1	USER'S GUIDE ASSY, MFC3320CN FOR GNR	√	
1-1	LF4094003	1	USER'S GUIDE, FAX1815C/1820C FOR GER/AUS		
1-1	LF4434003	1	USER'S GUIDE, MFC3220C FOR GER/AUS		
1-1	LF4179003	1	USER'S GUIDE, MFC3320CN FOR GER/AUS		
1-1	LF4094004	1	USER'S GUIDE, FAX1820C FOR UK/IRE/GNR, MFC3220C FOR UK/IRE/NOR/FIN/SWE/GNR		CHG
1-1	LF4179004	1	USER'S GUIDE, MFC3320CN FOR UK/IRE/NOR/FIN/SWE/GNR		
1-1	LF4094005	1	USER'S GUIDE, FAX1815C/1820C/MFC3220C FOR FRA		
1-1	LF4179005	1	USER'S GUIDE, MFC3320CN FOR FRA		
1-1	LF4094008	1	USER'S GUIDE, FAX1820C/MFC3220C FOR BEL <FRENCH>		
1-1	LF4296008	1	USER'S GUIDE, FAX1815C/FAX1820C/MFC3220C FOR BEL/CHE <DUTCH>		
1-1	LF4179008	1	USER'S GUIDE, MFC3320CN FOR BEL <FRENCH>		
1-1	LF4567008	1	USER'S GUIDE, MFC3320CN FOR BEL/CHE <DUTCH>		
1-1	LF4094009	1	USER'S GUIDE, FAX1820C/MFC3220C FOR NLD		
1-1	LF4179009	1	USER'S GUIDE, MFC3320CN FOR NLD		
1-1	LF4094010	1	USER'S GUIDE, FAX1815C/1820C/MFC3220C FOR CHE <GERMAN>		
1-1	LF4179010	1	USER'S GUIDE, MFC3320CN FOR CHE <GERMAN>		
1-1	LF4094013	1	USER'S GUIDE, FAX1820C/MFC3220C FOR DEN		
1-1	LF4179013	1	USER'S GUIDE, MFC3320CN FOR DEN		
1-1	LF4094015	1	USER'S GUIDE, FAX1815C/1820C/MFC3220C FOR SPA		
1-1	LF4179015	1	USER'S GUIDE, MFC3320CN FOR SPA		
1-1	LF4094016	1	USER'S GUIDE, FAX1820C/MFC3220C FOR ITA		
1-1	LF4179016	1	USER'S GUIDE, MFC3320CN FOR ITA		
1-1	LF4094018	1	USER'S GUIDE, FAX1815C/1820C/MFC3220C FOR POR		
1-1	LF4179018	1	USER'S GUIDE, MFC3320CN FOR POR		
1-1	LF4519056	1	USER'S GUIDE FOR HK/SIN/GUL/ARL/NZ		
1-1	LF4094007	1	USER'S GUIDE, FAX1820C FOR NOR		ADD
1-1	LF4094026	1	USER'S GUIDE, FAX1820C FOR SWE		ADD
1-1	LF4094012	1	USER'S GUIDE, FAX1820C FOR FIN		ADD
1-2	LE9641001	2	ADDRESS LABEL FOR FAX1815C/1820C/MFC3220C		
1-2	LE9967001	2	ADDRESS LABEL FOR MFC3320CN		

10. PACKING MATERIALS



List10(PACKING MATERIALS)

REF No	CODE	QTY	DESCRIPTION	RECOMMEND	REMARK
1	LF4095001	1	CARTON, BROTHER, FAX1815C FOR GER	√	
1	LF4114001	1	CARTON, BROTHER, FAX1820C FOR GER	√	
1	LF4156001	1	CARTON, BROTHER, MFC3220C FOR GER	√	
1	LF4180001	1	CARTON, BROTHER, MFC3220CN FOR GER	√	
1	LF4121001	1	CARTON, BROTHER, FAX1820C FOR UK/SIN/GUL/ARL/NZ	√	
1	LF4161001	1	CARTON, BROTHER, MFC3220C FOR UK	√	
1	LF4188001	1	CARTON, BROTHER, MFC3220CN FOR UK	√	
1	LF4103001	1	CARTON, BROTHER, FAX1815C FOR FRA	√	
1	LF4129001	1	CARTON, BROTHER, FAX1820C FOR FRA	√	
1	LF4166001	1	CARTON, BROTHER, MFC3220C FOR FRA	√	
1	LF4196001	1	CARTON, BROTHER, MFC3220CN FOR FRA	√	
1	LF4097001	1	CARTON, BROTHER, FAX1815C FOR CHE/AUS/SPA/POR	√	
1	LF4116001	1	CARTON, BROTHER, FAX1820C FOR BEL/NLD/CHE/IRE/DEN/AUS/SPA/ITA/POR/NOR/FIN/SWE/GNR	√	
1	LF4158001	1	CARTON, BROTHER, MFC3220C FOR BEL/NLD/CHE/IRE/DEN/AUS/SPA/ITA/POR/NOR/FIN/SWE/GNR	√	
1	LF4182001	1	CARTON, BROTHER, MFC3220CN FOR SPA/ITA	√	
1	LF4520001	1	CARTON, BROTHER, MFC3220C FOR HK/SIN/GUL/ARL/NZ	√	
2	LF4666001	1	BODY POLYSTYRENE FOAM ASSY, FAX1815C/MFC3220C/3220CN		
2	LF4671001	1	BODY POLYSTYRENE FOAM ASSY, FAX1820C		
3	LE3605001	1	BAG, 800X900H		
4	LF4099001	1	QUICK SETUP GUIDE, FAX1815C/1820C FOR GER/AUS		
4	LF4160001	1	QUICK SETUP GUIDE, MFC3220C FOR GER/AUS		
4	LF4184001	1	QUICK SETUP GUIDE, MFC3220CN FOR GER/AUS		
4	LF4124001	1	QUICK SETUP GUIDE, FAX1820C FOR UK/IRE		
4	LF4165001	1	QUICK SETUP GUIDE, MFC3220C FOR UK/IRE		
4	LF4192001	1	QUICK SETUP GUIDE, MFC3220CN FOR UK/IRE		
4	LF4106001	1	QUICK SETUP GUIDE, FAX1815C/1820C FOR FRA		
4	LF4169001	1	QUICK SETUP GUIDE, MFC3220C FOR FRA		
4	LF4199001	1	QUICK SETUP GUIDE, MFC3220CN FOR FRA		
4	LF4439001	1	QUICK SETUP GUIDE, FAX1815C/1820C FOR BEL/CHE<FRENCH>		
4	LF4485001	1	QUICK SETUP GUIDE, FAX1820C FOR BEL<DUTCH>		
4	LF4299001	1	QUICK SETUP GUIDE, MFC3220C FOR BEL/CHE<FRENCH>		
4	LF4570001	1	QUICK SETUP GUIDE, MFC3220CN FOR BEL/CHE<FRENCH>		
4	LF4298001	1	QUICK SETUP GUIDE, MFC3220C FOR BEL<DUTCH>		
4	LF4569001	1	QUICK SETUP GUIDE, MFC3220CN FOR BEL<DUTCH>		
4	LF4489001	1	QUICK SETUP GUIDE, FAX1820C FOR NLD		
4	LF4302001	1	QUICK SETUP GUIDE, MFC3220C FOR NLD		
4	LF4575001	1	QUICK SETUP GUIDE, MFC3220CN FOR NLD		
4	LF4438001	1	QUICK SETUP GUIDE, FAX1815C/1820C FOR CHE<GERMAN>		
4	LF4305001	1	QUICK SETUP GUIDE, MFC3220C FOR CHE<GERMAN>		
4	LF4578001	1	QUICK SETUP GUIDE, MFC3220CN FOR CHE<GERMAN>		
4	LF4495001	1	QUICK SETUP GUIDE, FAX1820C FOR DEN/NOR/FIN/SWE		CHG
4	LF4316001	1	QUICK SETUP GUIDE, MFC3220C FOR DEN/NOR/FIN/SWE		
4	LF4585001	1	QUICK SETUP GUIDE, MFC3220CN FOR DEN/NOR/FIN/SWE		
4	LF4444001	1	QUICK SETUP GUIDE, FAX1815C/1820C FOR SPA		
4	LF4323001	1	QUICK SETUP GUIDE, MFC3220C FOR SPA		
4	LF4422001	1	QUICK SETUP GUIDE, MFC3220CN FOR SPA		
4	LF4503001	1	QUICK SETUP GUIDE, FAX1820C FOR ITA		
4	LF4328001	1	QUICK SETUP GUIDE, MFC3220C FOR ITA		
4	LF4427001	1	QUICK SETUP GUIDE, MFC3220CN FOR ITA		
4	LF4448001	1	QUICK SETUP GUIDE, FAX1815C/1820C FOR POR		
4	LF4333001	1	QUICK SETUP GUIDE, MFC3220C FOR POR		
4	LF4592001	1	QUICK SETUP GUIDE, MFC3220CN FOR POR		
4	LF4511001	1	QUICK SETUP GUIDE, FAX1820C FOR NOR/FIN/SWE<ENGLISH>		DEL
4	LF4512001	1	QUICK SETUP GUIDE, FAX1820C FOR NOR		
4	LF4339001	1	QUICK SETUP GUIDE, MFC3220C FOR NOR/FIN/SWE<ENGLISH>		
4	LF4598001	1	QUICK SETUP GUIDE, MFC3220CN FOR NOR/FIN/SWE<ENGLISH>		
4	LF4340001	1	QUICK SETUP GUIDE, MFC3220C FOR NOR		
4	LF4599001	1	QUICK SETUP GUIDE, MFC3220CN FOR NOR		
4	LF4514001	1	QUICK SETUP GUIDE, FAX1820C FOR FIN		
4	LF4342001	1	QUICK SETUP GUIDE, MFC3220C FOR FIN		
4	LF4601001	1	QUICK SETUP GUIDE, MFC3220CN FOR FIN		
4	LF4513001	1	QUICK SETUP GUIDE, FAX1820C FOR SWE		
4	LF4341001	1	QUICK SETUP GUIDE, MFC3220C FOR SWE		
4	LF4600001	1	QUICK SETUP GUIDE, MFC3220CN FOR SWE		
4	LF4685001	1	QUICK SETUP GUIDE, FAX1820C FOR SIN/GUL/ARL/NZ		
4	LF4523001	1	QUICK SETUP GUIDE, MFC3220C FOR SIN/GUL/ARL/NZ		
4	LF4509001	1	QUICK SETUP GUIDE, FAX1820C FOR GNR		
4	LF4336001	1	QUICK SETUP GUIDE, MFC3220C FOR GNR		
4	LF4595001	1	QUICK SETUP GUIDE, MFC3220CN FOR GNR		
5	LF4135001	1	CARRIAGE STOPPER		

brother®

PL-FAX062
8CA741
Ver. J-1