

Epson P50 parts

Part Number	Referent number from picture	Description
1516753	1	TRAY CDR ASSY.,CA45,ASP
1478425	100	HOUSING LOWER ASSY.ASP,C691,EPPI
1108107	103	FOOT
1463694	106	GUIDE,STACKER,LEFT
1463725	107	GUIDE,STACKER,RIGHT
1465134	111	STACKER SUPPORT ASSY,C691,EPPI
1515339	112	COVER PRINTER ASSY.,D,CA45,EPPI
1465135	113	Ersetzt durch: 1557676
1469266	114	COVER,CASE
1507972	115	HOUSING,UPPER,B
2090717	124	LEAF SENSOR
2124467	126	HARNESS
2121250	127	HARNESS,DETECTOR,CASE,OPEN,B
1505727	128	HOLDER,OPEN,SENSOR
1463533	130	COVER,INK,TUBE
1506436	133	COVER STACKER ASSY.,CA45,EPPI
1505724	135	HOUSING,RIGHT
1510180	137	LABEL,INSTRUCTION,B
1494660	138	LABEL,GENUINE INK,T110/EURO
1474303	139	LABEL,CDR
1506410	140	HOUSING PANEL ASSY.,CA45,EPPI
1505725	141	DECORATION BELT,RIGHT
1505726	142	HOUSING,LEFT
1505729	143	DECORATION BELT,LEFT
2143578	200	BOARD ASSY.,MAIN
2125883	200	Ersetzt durch: 2143578
2116495	201	BOARD ASSY.,PANEL6318A,STANDARD
1465151	300	POWER SUPPLY ASSY,C691,PSE,EPPI
2121764	400	POWER CABLE
2121111	500	PRINTER MECHANISM,ASP
1473044	501	Ersetzt durch: 1487928
1487928	501	PAPER GUIDE FRONT ASSY,C691,ASP,EPPI
1463787	503	POROUS PAD,PAPER GUIDE,FRONT
1473045	504	FRAME EJ ASSY,C691,ASP,EPPI
1410323	505	TORSION SPRING,FRAME,EJ,LEFT
1410043	506	TORSION SPRING,FRAME,EJ
1410051	507	LEVER,PE
1447953	508	TORSION SPRING,LEVER,PE
2122827	509	MOTOR ASSY.,PF,C
1465137	511	PAPER GUIDE UPPER ASSY,C691,EPPI
1481233	512	HOLDER,APG
1465029	513	SPUR GEAR,28.8
1416886	514	COMPRESSION SPRING,2.25
1409938	515	SPUR GEAR,12.8
1468745	516	SPUR GEAR,33.6,B
1409943	517	COMPRESSION SPRING,0.97
1409945	518	COMBINATION GEAR,12.8,27
1409946	519	COMBINATION GEAR,14,22
1409999	520	SCALE,CR
2116693	521	MOTOR ASSY.,CR
1467981	522	PULLEY,DRIVEN,B
1262438	523	SHAFT,PULLEY,DRIVEN
1510062	524	HOLDER,PULLY,DRIVEN,B
1444296	525	GROUNDING WIRE,PFEJ
1473046	526	INK SYSTEM ASSY,C691,ASP,EPPI
1409580	527	EXTENSION SPRING,0.8
1481010	528	LOCK,CR

Epson P50 parts

Part Number	Referent number from picture	Description
1474961	529	COMPRESSION SPRING,0.98
1292709	530	TIMING BELT,CR
1409935	531	SHAFT,GUIDE,CR
1473047	532	CARRIAGE ASSY,C691,ASP,EPPI
1466288	533	CABLE HEAD ASSY,C691,EPPI
2121202	534	HARNESS,DETECTOR,GUIDE,CDR,B
2020393	536	DETECTOR,LEAF,B2
1424204	576	SHEET,MIST
1424205	577	SHEET,MIST,B
1426444	578	SHEET,MIST,FRAME MAIN
1426445	579	SHEET,MIST,PAPER GUIDE,UPPER
1483950	580	SHEET,MIST,LD
1483951	581	SHEET,MIST,LD,B
2090532	600	PHOTO INTERRUPTER,TLP1243(C8)
F180000	700	PRINT HEAD
1262694	701	SCALE,PF
1212722	702	DOUBLE SIDED TAPE,D21
2116697	703	CABLE,ENCODER,PF,
2116736	704	BOARD ASSY.,ENCODER,PF
1438752	705	SPUR GEAR,26.5
1465131	707	ASF ASSY,C691,EPPI
1473588	708	GUIDE,ROLLER,LD
1295162	709	TORSION SPRING,137.7
1075955	710	ROLLER,LD,B
1447353	711	HOLDER ROLLER RETARD ASSY.,M,C653,EPPI
1409638	712	COMBINATION GEAR,16.8,32.8
1474785	713	LEVER,CHANGE,B
1467962	714	SPUR,GEAR,16,B
1250632	715	COMPRESSION SPRING,2.36
1465612	716	COVER CARTRIDGE ASSY,C691,EPPI
1469197	717	TRAY,POROUS PAD,ASSY.,B
1507070	718	CSIC ASSY.,CA45,EPPI
1431479	719	COLOR,BLOCK
1431478	720	HINGE,COVER,CARTRIDGE
1431483	721	COVER,CABLE,HEAD,INNER
1431482	722	COVER,CABLE,HEAD
1499173	725	POROUS PAD,HOUSING,LOWER
1499152	726	POROUS PAD INK,EJ,CAP,LOWER,B
1466932	730	SHAFT ROLLER,LD ASSY,C691,EPPI
1443530	NON FIG	INK CART.UNBOXED,BK-SS,DYE,H62F,EC,AS
1443531	NON FIG	INK CART.UNBOXED,C-SS,DYE,H62F,EC,AS
1443534	NON FIG	INK CART.UNBOXED,LC-SS,DYE,H62F,EC,AS
1443535	NON FIG	INK CART.UNBOXED,LM-SS,DYE,H62F,EC,AS
1443532	NON FIG	INK CART.UNBOXED,M-SS,DYE,H62F,EC,AS
1443533	NON FIG	INK CART.UNBOXED,Y-SS,DYE,H62F,EC,AS
4116102	NON FIG	SETTING UP MANUAL
3104347	NON FIG	SOFTWARE CD,HOME/EXPORT