

OEL Recommended Spare Parts List

B4400



Revision 17

Rev	Unit Name	No.	Part No.	Part Name	Qty /Unit	Recommended Qty/Year			Remarks	Special (New Parts:*)	Del/ Add	Remarks for environment
						per 500	per 1000	per 2000				
	For B4400	1	43653501	Roller Assy. -HOP	1	3	6	12		*		
	For B4400	2	43238401	Roller-Hopping	1	3	6	12		*		
	For B4400	3	43329501	Bearing-Hopping	2	6	12	24		*		
	For B4400	4	43400201	Gear Assy. -Clatch	1	3	6	12		*		
16	For B4400	5	42174302	Roller-Regist	1	3	6	12				
	For B4400	6	4PP4083-6031P001	BEARING R	1	3	6	12				
	For B4400	7	43400501	Roller-Pressure	1	3	6	12		*		
	For B4400	8	41279501	Holder-Regist L	1	3	6	12				
	For B4400	9	41279601	Holder-Regist R	1	3	6	12				
	For B4400	10	41279801	Gear-Pressure	1	3	6	12				
	For B4400	11	41279401	Bearing-Pressure	2	6	12	24				
	For B4400	12	41281201	Spring-Tension	2	6	12	24				
	For B4400	13	41280401	Plate-Contact PA	1	3	6	12				
	For B4400	14	41279301	Bearing-Regist L	1	3	6	12				
	For B4400	15	41279701	Gear-Regist	1	3	6	12				
	For B4400	16	43979601	Roller-Transfer (282)	1	3	6	12		*		
	For B4400	17	43330101	Bearing-TR	2	6	12	24		*		
14	For B4400	18	44002201	Roller-Back up	1	3	6	12				
	For B4400	19	41584101	Spring-Bias	2	6	12	24				
	For B4400	20	43448601	Holder-BU	2	6	12	24		*		
	For B4400	21	41584201	Bearing-Ball	2	6	12	24				
	For B4400	22	43614001	Lever-Assy. -Reset_L	1	3	6	12		*		
	For B4400	23	3PP4083-6054P001	RESET LEVER R	1	3	6	12				
	For B4400	24	42551201	Arm-Switch	1	3	6	12				
	For B4400	25	4PP4083-6057P001	RESET SPRING	1	3	6	12				
	For B4400	26	43329001	Gear-HT	1	3	6	12		*		
	For B4400	27	4PP4083-6081P001	IDLE GEAR C	1	3	6	12				
	For B4400	28	4PP4083-6083P001	SENSOR PLATE (IN)	2	6	12	24				
	For B4400	29	43758301	Sensor Assy. - Lever_Eject	1	3	6	12				
	For B4400	30	41027701	Sensor Wire Assembly	1	3	6	12				
	For B4400	31	42468801	Sensor- Toner (Adhesive)	1	3	6	12				
	For B4400	32	43979801	Sheet-Discharge	1	3	6	12	ECO-B4400-012	*		
	For B4400	33	3PB4083-6089P001	DISELECTRIFICATION FILM	1	3	6	12				
	For B4400	34-b	43435702	Heat Assy.	1	10	20	40	230V	*		
	For B4400	35	40772503	Roller Assy. -Eject	1	3	6	12		*		
	For B4400	36-a	42145708	Cover Assy. -Front	1	3	6	12		*		
	For B4400	37-a	43540501	Cover Assy. - Stacker (L)	1	3	6	12		*		
	For B4400	38-a	43330801	Holder-Head	1	3	6	12		*		
	For B4400	39	43401501	Film-FG	1	3	6	12		*		
	For B4400	40	43467601	Spring-Head	2	6	12	24		*		

Rev	Unit Name	No.	Part No.	Part Name	Qty /Unit	Recommended Qty/Year			Remarks	Special (New Parts:*)	Del/ Add	Remarks for environment
						per 500	per 1000	per 2000				
	For B4400	41	2381031P0008	TW-VF-24-01X06-272	1	5	10	20		*		
	For B4400	42	43330901	Contact-Head	1	3	6	12		*		
15	For B4400	43	44706401	LED Head Unit-51TRB	1	5	10	20	Thyristor LED Head, ECO-B4400-030	*		
	For B4400	44	43435301	Frame Subassy. -Lower	1	3	6	12		*		
	For B4400	45	42596601	Damper-Oil	1	3	6	12				
	For B4400	46	43328701	Bracket-Motor_Caulking	1	3	6	12		*		
	For B4400	47	43329401	Plate-FG_HP	1	3	6	12		*		
	For B4400	48	43400001	Motor-DC (Main)	1	3	6	12		*		
	For B4400	49	43400101	Motor-Pulse (Regist)	1	3	6	12		*		
	For B4400	50	43328901	Gear-M3	1	3	6	12		*		
	For B4400	51	43328801	Gear-M2	1	3	6	12		*		
	For B4400	52	43329101	Gear-R2	1	3	6	12		*		
	For B4400	53	4PP4120-1210P001	WASHER C	1	3	6	12				
	For B4400	54	43448701	Collar	2	6	12	24		*		
	For B4400	55	43435601	Guide-Paper R (Adhesive)	1	3	6	12		*		
	For B4400	56	43434801	Plate Assy. -Base	1	3	6	12		*		
	For B4400	57	4YC4061-5115P001	POLYETHYLENE TAPE	2	6	12	24	L=90mm			
	For B4400	58	40828301	Guide-PaperH	2	6	12	24				
	For B4400	59	4PB4013-3501P002	CS-RING (CS3-SUS)	2	6	12	24				
	For B4400	60-a	43517901	Guide-Cassette L Assy.	1	3	6	12		*		
	For B4400	61-a	43435101	Guide-Cassette R Assy.	1	3	6	12		*		
	For B4400	62	3PP4083-7660P001	BEAM PLATE	2	6	12	24				
	For B4400	63	43330501	Plate-FG_Beam	2	6	12	24		*		
	For B4400	64	4PP4083-7667P001	PAPER END SENSOR LEVER	1	3	6	12				
	For B4400	65	3PP4083-6154P001	CASSETTE DETECTION LEVER	1	3	6	12				
	For B4400	66	43401701	Insulator	1	3	6	12		*		
15	For B4400	67-a	44866102	Board-Maintenance-GSA (B4400-OEL)	1	5	10	20	B4400 OEL, ECO-B4400-034	*		
15	For B4400	67-c	44866104	Board-Maintenance-GSA (B4400L-OEL)	1	5	10	20	B4400L OEL, ECO-B4400-034	*		
	For B4400	68-b	43113101	PN282PowerSupplyUnit (220-240V)	1	5	10	20	230V	*		
17	For B4400	69-a	44838201	OR-Board-HLC	1	5	10	20	ECO-B4400-034. ECO-B4400-044 : Choose HLC or HLD by the destination. Refer to Applicable list.	*		
17	For B4400	69-b	45612901	OR-Board-HLD	1	5	10	20	CO-B4400-044 : Choose HLC or HLD by the destination. Refer to Applicable list.	*	A	
	For B4400	70	2381015P0003	TW-VF-30-0.1X0.8-75	1	5	10	20				
	For B4400	71	43275301	JST14P-JST6P, JST8P	1	5	10	20		*		
	For B4400	72	43400301	Motor-Fan	1	3	6	12		*		
	For B4400	73-a	42209608	Cassette Assy. -Paper	1	3	6	12		*		
	For B4400	74	42146201	Plate-Guide	1	3	6	12				
	For B4400	75	42146901	Plate-Shield	1	3	6	12				

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Special (New Parts:*)	Del/ Add	Remarks for environment
						per 500	per 1000	per 2000				
	For B4400	76-a	42146803	Stacker Assy. -FU	1	3	6	12		*		
	For B4400	77-a	43521301	Frame Assy. -OP Panel	1	3	6	12	B4400	*		
	For B4400	77-c	43521305	Frame Assy. -OP Panel	1	3	6	12	OEL B4400L	*		
	For B4400	78-a	43520901	Cover Assy. -Upper	1	3	6	12		*		
	For B4400	79-a	42129605	Cover-IF	1	3	6	12		*		
	For B4400	83	42264116	Board-I/F NIC	1	3	6	12	NetWork OEL B4400n	*		
	For B4400	84	43329301	Boss-Hopping	1	3	6	12		*		
	For B4400	85	43400601	Shaft-Hopping	1	3	6	12		*		
	For B4400	86	43399601	Stopper-Hopping	1	3	6	12		*		
	For B4400	87	43329901	Collar	1	3	6	12		*		
	For B4400	90	43329601	Gear-HP1	1	3	6	12		*		
	For B4400	91	43329801	Gear-HP2	1	3	6	12		*		
	For B4400	92	43329701	Gear-HP3	1	3	6	12		*		
	For B4400	93	43598801	Collar-Reset-Lever	1	3	6	12		*		
	For B4400	94	4PP4083-6194P001	DAMPER GEAR	1	3	6	12				
	For B4400	95	42797101	Spring-Sensor_IN	1	3	6	12				
	For B4400	96	41415801	Spring-WriteSensor	1	3	6	12				
	For B4400	97	42679901	Plate-Damper (Culking)	1	3	6	12				
	For B4400	98	42661401	Guide-Paper	1	3	6	12				
	For B4400	99	42657701	Gear-Reg (one-way)	1	3	6	12				
	For B4400	100	43330001	Gear-TR	1	3	6	12		*		
	For B4400	101	43401401	Spring-TR	2	6	12	24		*		
	For B4400	103	42849201	Film-Support (OP)	1	3	6	12				
	For B4400	106	40997102	Cord-Assy. OP	1	5	10	20				
	For B4400	121	3PP4122-1171P001	PAPER INDICATION LEVER	1	5	19	20		*		
15	For B4400	123	44838701	OR-Board-TMA	1	5	10	20	ECO-B4400-034	*		