

# OEL Recommended Spare Parts List

C9200/C9400



Revision 8

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Del/ Add	Remarks for environment
						per 500	per 1000	per 2000			
	Main Assy	1	41481201	Cover Assy.-R	1	3	6	12			
	Main Assy	2	41484905	Cassette Assy-OEL/APS/ODA	1	3	6	12	OEL/APS		
	Main Assy	2	41484906	Cassette Assy(ODA)_mainte	1	3	6	12	ODA ECO-C9400-054		
	Main Assy	3	41353701	Cover-Front-CS	1	3	6	12			
	Main Assy	4	41277901	Cover-Blank	1	3	6	12			
	Main Assy	5	41276401	Cover-Front	1	3	6	12	OEL/APS		
	Main Assy	5	41749602	Cover Assy.-Front(ODA)	1	3	6	12	ODA ECO-C9400-054		
	Main Assy	6	41277401	Cover-Side(L)	1	3	6	12			
	Main Assy	7	41484201	Stacker-Face-Up-Assy	1	3	6	12			
	Main Assy	8	41276501	Cover-Rear	1	3	6	12			
	Main Assy	9	41484603	Cover Assy.-MF(OKI)	1	3	6	12			
	Main Assy	10	41493003	MPT.Assy-703(OKI)	1	3	6	12	OEL/APS		
	Main Assy	11	41297101	Plate-Top	1	3	6	12			
	Main Assy	12	40325101	Gear-z68	2	6	12	24			
	Main Assy	13	41278001	Frame-Top	1	3	6	12	OEL/APS		
	Main Assy	14	41515108	Board-K73	1	3	6	12	1200dpi		
	Main Assy	14	41515112	Board-K73	1	3	6	12	600dpi#C		
	Main Assy	15	41490702	Motor-Fan-80	1	3	6	12			
	Main Assy	16	41275702	Microswitch-Assy	1	3	6	12			
	Main Assy	20	816A2323M0000	NM93C66N-NW	1	3	6	12			
	Main Assy	21	PB4013-3100P006	Cup Screw A	31	40	80	120			
	Main Assy	26	41716819	Board- SWA	1	3	6	12	1200dpi		
	Main Assy	26	41716820	Board- SWA	1	3	6	12	600dpi		
	Main Assy	27	8164323M0000	M93C86-WBN6P	1	3	6	12			
	Main Assy	28	41469504	Board-TNY	1	3	6	12			
	Main Assy	34	41848501	Cover Assy.-CU(Maintenance)	1	3	6	12			
	Main Assy	35	41278601	Guide-Rail(A)	1	3	6	12	ECO-C9400-143		
	Main Assy	36	41278701	Guide-Rail(B)	1	3	6	12			
	Main Assy	37	41410201	Motor-Fan	1	3	6	12			
	Main Assy	38	41467401	Plate-FG(Centoro)	1	3	6	12			
	Main Assy	39	41254601	Plate-Blank	1	3	6	12	ECO-C9400-143		
	Main Assy	41	41366501	Limiter-2WAY(Front)	1	3	6	12			
	Main Assy	42	41366601	Limiter-2WAY(Rear)	1	3	6	12			
	Toop Cover Assembly	1	41484401	Cover Assy.-Stacker	1	3	6	12			
	Toop Cover Assembly	2	41502301	Head.Assy-703(1200)	4	12	24	48	ODA/OEL/APS		
	Toop Cover Assembly	2	41502302	Head.Assy-703(600)	4	12	24	48	ODA/OEL/APS		
	Toop Cover Assembly	3	40861001	Spring-Head	8	24	48	96			
	Toop Cover Assembly	4	41257902	Board-Y71	1	3	6	12			
	Toop Cover Assembly	5	41349801	Lever-Stacker-Full	1	3	6	12			
	Toop Cover Assembly	6	41487101	Cover Assy.-inner(SUB)	1	3	6	12	OEL/APS		
	Toop Cover Assembly	7	41514103	Cable Assy.-Head-M	1	3	6	12			
	Toop Cover Assembly	8	41514104	Cable Assy.-Head-C	1	3	6	12			
	Toop Cover Assembly	9	41514102	Cable Assy.-Head-Y	1	3	6	12			
	Toop Cover Assembly	10	41514101	Cable Assy.-Head-K	1	3	6	12			
	Toop Cover Assembly	11	41703701	Sensor-Toner-Assy	4	12	24	48			
	Toop Cover Assembly	12	41484501	Frame Assy.-OP_PANEL	1	3	6	12			
	Toop Cover Assembly	13	40866207	Plate-OP Panel	1	3	6	12	1200dpi		
	Toop Cover Assembly	13	40866211	Plate-OP Panel	1	3	6	12	600dpi		
	Toop Cover Assembly	14	2381003P0018	HCUJ/TW-VFM/6F-680	1	3	6	12	ECO-C9400-070		
	Toop Cover Assembly	15	41484701	Guide Assy.-Eject	1	3	6	12			
	Toop Cover Assembly	16	2251001P0260	9608S-26A-G2C	4	12	24	48			
	Toop Cover Assembly	17	41454403	3110KL-09W-B49 Motor-Fan	1	3	6	12			
	Printer Unit Chassis	1	41189701	Drum contact assembly	4	12	24	48			
	Printer Unit Chassis	2	41483201	Roller Assy.-Regist_A	1	3	6	12			
	Printer Unit Chassis	3	41483301	Roller Assy.-Regist_B	1	3	6	12			
	Printer Unit Chassis	4	41628401	Gear-RE3	1	3	6	12			
	Printer Unit Chassis	5	41187101	Gear-Assy Clutch	1	3	6	12			
	Printer Unit Chassis	6	41483401	Motor Assy.-Regist	1	3	6	12			
	Printer Unit Chassis	7	41483701	Motor Assy.-Fan	1	3	6	12			
	Printer Unit Chassis	8	41491001	Sensor Assy.-Regist	1	3	6	12			
	Printer Unit Chassis	9	41744001	Solenoid-Shutter Assy	1	3	6	12			
	Printer Unit Chassis	10	41743901	Plate-Shutter A3(Adhesive)	1	3	6	12			
	Printer Unit Chassis	11	41744601	Spring-Shutter A3	1	3	6	12			
	Printer Unit Chassis	12	41486801	Guide Assy.-sheet	1	3	6	12			
	Printer Unit Chassis	13	41483101	Printer Unit-Chassis	1	3	6	12	OEL/APS		
	Printer Unit Chassis	16	40841601	Sensor-Ent1	1	3	6	12			
	Printer Unit Chassis	17	41578501	Lever-ENT2	1	3	6	12			
	Printer Unit Chassis	18	40841801	Sensor-Write	1	3	6	12			
	Printer Unit Chassis	19	41258301	Board-R71	1	3	6	12			

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Del/ Add	Remarks for environment
						per 500	per 1000	per 2000			
	Printer Unit Chasssis	20	41486601	Magnet Assy.-DUP	1	3	6	12			
	Printer Unit Chasssis	21	41393901	Solenoid-Sheet-Assy	1	3	6	12			
	Printer Unit Chasssis	22	41095901	Roller-Feed-C (A3)	1	3	6	12			
	Printer Unit Chasssis	23	PP4076-3949P001	Bush	1	3	6	12			
	Printer Unit Chasssis	24	PP4043-4489P001	Bearing-Feed	1	3	6	12			
	Printer Unit Chasssis	25	41073601	Sensor Assy.-Exit	1	3	6	12			
	Printer Unit Chasssis	26	40841301	Lever-Lock-Heat L	1	3	6	12			
	Printer Unit Chasssis	27	41628301	Spring-Lock Fuser	2	6	12	24			
	Printer Unit Chasssis	28	41483901	Motor Assy.-Belt	1	3	6	12			
	Printer Unit Chasssis	29	40841401	Lever-Lock-Heat R	1	3	6	12			
	Printer Unit Chasssis	30	41483801	Motor Assy.-Main	1	3	6	12			
	Printer Unit Chasssis	31	41484001	Plate Assy.-Side(L)	1	3	6	12			
	Printer Unit Chasssis	32	40850201	Contact Assy	1	3	6	12			
	Printer Unit Chasssis	33	41303401	PWR unit-ACDC Switch(115V)	1	3	6	12			
	Printer Unit Chasssis	33	41303501	PWR unit-ACDC Switch(230V)	1	3	6	12			
	Printer Unit Chasssis	34	40737601	PWR unit-(high voltage)	1	3	6	12			
	Printer Unit Chasssis	35	2381003P0030	HCUJ/TW-VFH/19F-500	1	3	6	12	ECO-C9400-070		
	Printer Unit Chasssis	36	41500101	Sheet-Insulation	1	3	6	12			
	Printer Unit Chasssis	40	41346301	Holder Assy.-Belt Fuse	2	6	12	24			
	Printer Unit Chasssis	41	41589501	Sheet-Insulation HV	1	3	6	12			
	Printer Unit Chasssis	42	40197103	Motor-Fan(CU)	1	3	6	12			
	Printer Unit Chasssis	43	43627501	Motor-Fan_Rework	1	3	6	12			
	Paper Tray Guide	1	41481301	Guide Assy.-R_1st	1	3	6	12			
	Paper Tray Guide	2	41766501	Roller-Feed	1	3	6	12			
	Paper Tray Guide	3	41488401	Roller-Feed-A3	1	3	6	12			
	Paper Tray Guide	4	41685401	Motor-Pulse(Hop)	1	3	6	12			
	Paper Tray Guide	5	41515701	Board-A73	1	3	6	12			
	Paper Tray Guide	6	41503001	Gear Assy.-Cluch	1	3	6	12			
	Paper Tray Guide	7	41502601	Rubber-Foot	4	12	24	48			
	Paper Tray Guide	8	41844101	Board-B73 Rework	1	3	6	12			
	Paper Tray Guide	9	2201000P0140	9714N-14Z02-G4C	1	3	6	12			
	Paper Tray Guide	18	41488301	Gear Assy.-cluch	1	3	6	12			
	High Capacity Tray Unit,2nd_3rd	1	41546901	Guide Assy.-R-Opt	1	3	6	12			
	High Capacity Tray Unit,2nd_3rd	1	41546903	Guide Assy.-R-Opt	1	3	6	12			
	High Capacity Tray Unit,2nd_3rd	2	41766501	Roller-Feed	3	9	18	36			
	High Capacity Tray Unit,2nd_3rd	3	41488401	Roller-Feed-A3	1	3	6	12			
	High Capacity Tray Unit,2nd_3rd	4	41635101	Plate-C	1	3	6	12			
	High Capacity Tray Unit,2nd_3rd	5	41844101	Board-B73 Rework	1	3	6	12	ECO-C9400-061		
	High Capacity Tray Unit,2nd_3rd	6	41503001	Gear Assy.-Cluch	1	3	6	12			
	High Capacity Tray Unit,2nd_3rd	7	41502601	Rubber-Foot	4	12	24	48			
	High Capacity Tray Unit,2nd_3rd	9	2201000P0140	9714N-14Z02-G4C	1	3	6	12			
	High Capacity Tray Unit,2nd_3rd	18	41488301	Gear Assy.-cluch	1	3	6	12			
	High Capacity Tray Unit,2nd_3rd	19	41547805	Cassette Assy.-Opt-O	1	3	6	12	OEL/APS		
	High Capacity Tray Unit,2nd_3rd	20	41503601	Cover-Side(L)-Opt	1	3	6	12			
	High Capacity Tray Unit,2nd_3rd	21	41503801	Cover-Rear-Opt	1	3	6	12			
	High Capacity Tray Unit,2nd_3rd	22	41780303	Board-V7X	1	3	6	24			
	High Capacity Tray Unit,2nd_3rd	23	41844101	Board-B73 Rework	1	3	6	12			
	High Capacity Tray Unit,2nd_3rd	24	41503701	Cover-Side(R)Sub-Opt	1	3	6	12			
	High Capacity Tray Unit,2nd_3rd	25	41546501	Cover Assy.-R-Opt	1	3	6	12			
	High Capacity Tray Unit,2nd_3rd	25	41546503	Cover Assy.-R-Opt	1	3	6	12			