


OEL Disassembly Drawing

ML5520/ML5521




Revision 6


Printer General Assy




Upper Cover Assy



Printer Unit




Carriage Assy




Option Spare Parts

[Pull-Tractor]



[Bottom-Tractor]



[I/F Board]

