





1 Press [Reset].



The RESET menu is displayed.




2 Select CHANGE TONER using [◀] and [▶], then press [OK].



The color of the toner cartridge is displayed.



3 Select the toner cartridge of which you want to reset the counter using [◀] and [▶], then press [OK].



A confirmation message is displayed.



4 Press [OK].

The printer does not initialize the counter if you press [Online] without pressing [OK].



NOTE

If the message <1G CHG."color" TNR> appears after resetting the counter of the toner cartridge, remove the replaced toner cartridge, hold the toner cartridge so that its tab is at the bottom, shake the cartridge up and down forcefully again to evenly distribute the toner inside the cartridge, and then install the toner cartridge.